WIRELESS PHONE - QUICK USER GUIDE

On/Off

* *Press and hold PWR 2 chirps ON, 1 chirp OFF*

MAKE A CALL

* *Press START to get dial tone*

HANG UP

* *Press END. Be sure to do this at the end of each call*

ANSWER CALL

* *Press START Line indicator comes on steady when the call is answered*

HOLD

* *Press HOLD*

TAKE OFF HOLD

* *Press LINE followed by the digit for the line which will be flashing*

MUTE ON/OFF

* *Press FCN twice and then 1*

FUNCTION

* *Press and hold FCN while off hook allows you to scroll throughmenu screens and change user settings*

TRANSFER A CALL

* *Press FCN twice and then 2*
* *Dial the number required*
* *Talk,then press end to transfer the call*
* *To return to the caller in the event of no answer or engaged tone,press LINE then 0*

ACCESS VOICEMAIL

* *When mail has been received MSG will flash on menu screen*
* *Press FCN twice and then 4, this will connect you to the voicemail system*
* *Follow standard voicemail menu procedure*

FEATURE ACCESS CODES

* *As per standard handset i.e. #61 to divert call*
* *See Telecomms web site for further features*

TO REMOVE ALL FEATURES

* *Dial #65 press FCN * for yes*